



Application method

Mechanical descaling of washing machines



Occupational safety

Follow operating instructions.

Use personal protective equipment!



Follow the skincare plan!



Step 1: Dosing and preparing of the ready-to-use solution

Prepare product in a measuring cup in line with dosage table (observe liquor ratio).

Machine size Dosage

5 kg 400 ml to 2 litres

8 kg 640 ml to 3.2 litres

10 kg 800 ml to 4 litres



Step 2: Selecting/starting of the programme

Select 60 °C wash programme without prewash, with longest possible soak time (10-15 minutes) and without spin, and start without laundry.



The safety advice and instructions for use on the containers, the product information and the safety data sheet must be observed. Please also observe the cleaning and maintenance recommendations of the manufacturers as well as the instruction manual of the machines and equipment used.



Application method

Mechanical descaling of washing machines



Step 3: Adding the product

Add product into the detergent drawer (main wash compartment) of the laundry machine during or after the water has filled the machine. Rinse the chamber with 500 ml of water at the end if required.

Step 4: Thermal disinfection

Run laundry machine again on a 90 °C wash programme (10-minute soak), without prewash, without detergent or laundry and without spin to ensure a hygienically clean machine.



The safety advice and instructions for use on the containers, the product information and the safety data sheet must be observed. Please also observe the cleaning and maintenance recommendations of the manufacturers as well as the instruction manual of the machines and equipment used.