



Application method

Removing handball wax and resin

Handball wax and resin can leave difficult-to-remove stains on sports floorings and surfaces. Resinex can be used to remove these stains without damaging or removing the polymer dispersion layer on the flooring.



Step 1: Remove coarse dirt

Sweep or damp wipe to remove coarse, loose dirt.



Step 2: Prepare cleaning solution

Use a funnel or measuring cup to fill a suitable foam spray bottle or pressure sprayer with Resinex. Remove any drops or spilled product immediately.

Follow operating instructions. Wear personal protective equipment.



Step 3: Apply product

Foam soiled areas with Resinex. In the case of large-scale soiling, add the undiluted product to the floor and distribute with a flat mop.



The safety advice and instructions for use on the containers, the product information and the safety data sheet must be observed. Please also observe the cleaning and maintenance recommendations of the manufacturers as well as the instruction manual of the machines and equipment used.



Application method

Removing handball wax and resin



Step 4: Scrub dirt

Use a wooden or plastic spatula to remove heavy soiling, or scrub with a non-scratch hand pad. Use a rotary floor machine and suitable pad to scrub large soiled areas.



Step 5: Prepare scrubber drier

Correctly separate the cleaning machine from the charging device. Affix the pad holder or brush in line with the manufacturer's specifications. Check float gauge is working correctly. Fill cleaning machine with cold water and add detergent.



Step 6: Clean the surface systematically

Start vacuum and brush motor. Check quantity of water. Deploy brush head or pad holder and suction foot. Run machine over the area in even, overlapping strokes.



The safety advice and instructions for use on the containers, the product information and the safety data sheet must be observed. Please also observe the cleaning and maintenance recommendations of the manufacturers as well as the instruction manual of the machines and equipment used.



Application method

Removing handball wax and resin



Step 7: Cleaning surfaces

Test material compatibility first!

Foam soiled areas with Resinex. Use a non-scratch pad or sponge to scrub dirt if needed. Use a Torvan cleaning solution (or similar) to remove loosened dirt and product residue.



Step 8: Clean tools

Dispose of the dirty solution correctly, rinse out the dirt and freshwater tank and then clean with a damp cloth. Clean the rough dirt and freshwater filters. Open the machine lid and allow the machine to dry. Cleaning textiles should be washed with laundry.



The safety advice and instructions for use on the containers, the product information and the safety data sheet must be observed. Please also observe the cleaning and maintenance recommendations of the manufacturers as well as the instruction manual of the machines and equipment used.